KITEC *Functions*

Option

ECO	PRO	MAX	*Functions*	*Subfunctions*
			Right mouse button	**Context menue**
			Linkk objects	**via button bar**
			Analyse sensor	
			Engine controls	
			File	
			Load image	
			Save image	
			Save image sequence	
			TWAIN Acquire	
			TWAIN	
			Print image	
			Print log	
			Printer setup	
			Video	
			On / Off	
			Freeze frame	
			Display	
			Select Video source	if more than one source available
			Measure	
			Distance	Point to point
				Point to point with subsidiary lines
				Point to line
				Circle to circle
				Circle to line
				Chain dimension
				Distance to DXF
			Hardness measurement	
			Circular area difference	
			Circular area difference 3 circles	
			Pinhole	
			Polygon difference	
			Angle	3 point
				4 point
				A dimension
				Z dimension
			Area	Circle
				Polygon
				Freehand figure
			Special cicle measurements	Diameter MCC
				Diameter MIC
				Gaussian form deviation
				Tschebyscheff form deviation
				Diameter LSC
				Wall thickness
			Borers - Cutters	Measurement WQ
				Mesurement SU
				Effektive diameter
				Angle in circle
				Crosshairs, simple and rotatable
				Distance PP (subsidiary circle)
				Angle 4C
				Distance PP plus angle
				Measurement RZ
				Clearance angle I
				Clearance angle II
				Clearance angle I plus chip angle
				Clearance angle II plus chip angle
				Chip angle

Option

				Subfunctions
			ircle	
			Circle segment	
			Numbering	
			Material fraction	
			Shut down	
			Reference	
			Crosshairs	Fixed
				Simple
				Simple, rotatable
				Doubled
				Doubled, rotatable
				Variable angle
				V angle
				Off
			Scale	On / Off
			Screen	Reticule
				Tolerance rings
				Multiforn screen
				Overlay
				DXF Overlay
			Text with circle	
			Text with arrow	
			Text input	
			Draw sharp	
			Settings	
			Character color	6 differrent
			Line thickness	1 to 3 pixels
			Font	
			Measurement systems	up to 100 items
			Calibrate	manual
				automatic dot matrix
				automatic ring structure
			Scale vertical	
			Program options	see table Program options
			Menu selection	
			Quick select buttons	
			Load settings	
			Change password	
			Save settings	
			Table	
			Add object	
			Remove object	
			Dimension object	
			Show table (Button on table window)	Save as ASCII table
				Save as DXF file
			Display Excel / Open Office table	If program is installed
			Draw table	
			Load table	
			Save table	
			Table new	
			Help	
			Show help	
			About the program	
			Archive	if available
			Launch archive	
			Transfer new image to archive	
			Return current image to arcive	
			Other function buttons	Copy (to clipboard)
				Insert (from clipboard)
			Pixel magnifier	

KITEC *Program options*

Option

ECO	PRO	MAX	*Program option*	*Subfunction*
			General	Language selection
				Lauch DoubleCheck automatically
				Save Font
				Confirm lens
				Preferred image format
				Display MT functions
				End warning re. changed configurations
			Measuring functions	Table entry with right mouse click
				Distance measurements in XY coordinates
				Automatice edge finding (no live picture)
				Angle in degree-minute-second
				Excel- / Open Office (Keywords) per line
				Excel- / Open Office (Keywords) several images
				Digital places
			Analyse object	Diameter
				Circularity
				Circumferrence
				Surface area
				X extension
				Y extension
			Live image window	Reflect live picture horizontically (Hardware dependant)
				Reflect live picture vertically (Hardware dependant)
				Display measurement values
				Display date / time
				Mouse pointer in measurement window
				Crosshair line type
			Extras	SU measurement with subsidiary line
				Storage location for Excel / Open Office tables
				Enter table name in 'new table'
				Show crosshair measurements
			DXF loading window	Show DXF file name